



COMFORT+

Warm Air Distribution System

CE

The COMFORT+ Warm Air Distribution system is a recovery of hot air via a chimney heat exchanger which consists of taking the heat produced a stove and distributing it to selected rooms.

IDEAL
FOR
BUNGALOWS

Fan Unit

To extract and
despatch warm air

Air Inlet Vent

Take cold air
from the room

Switch

Benefits

- Heat another 4 rooms
- Exceptional value
- Optimize output of the stove
- Quick and easy to install
- 10 year guarantee
- CERIC tested



Air distribution network

To carry off warm air

Air Outlet Vents

To distribute warm air
into the rooms




Thermostatic control

To regulate system temperatures





COMFORT+


Warm Air Distribution System



Accessories



Diameters



Features

- Thermostatically controlled hot air heat distribution.
- Low power and various size fans available.
- Heat from renewable source.
- Complete range of accessories to suit your requirements.

Double Skin Duct for ventilation & air conditioning

Flexalu acoustique
Perforated aluminium / glass wool insulation
25mm / aluminium 1050



Flexalu thermique
Aluminium / glass wool insulation 25mm /
aluminium 1050



Phoni Alu
Phonic & thermal insulation / fire resistance: M1
outside - M0 inside

